

Sistema® FreshWorks™

Sistema® FreshWorks™ Produce Saver helps keep produce fresher longer. This food storage container features a FreshVent™ that allows needed airflow and a unique CrispTray™ that separates produce from moisture.

FreshWorks™ containers work best when the tray and vented lid are used at the same time and are ideal for fresh produce rather than pre-packaged fruits, vegetables or salads. Keep pre-packaged produce in their sealed containers until you are ready to use them.



Tips and Hints

Here are some tips for extending the freshness of fruits and vegetables with Sistema® FreshWorks™:

1. Remove produce from grocery packaging
2. Do not cut or rinse produce prior to storage
3. Place fresh fruits or vegetables in FreshWorks™ with the tray in the bottom and the lid attached to the top of the container.
4. Store FreshWorks™ in the refrigerator
5. Wash fruits and vegetables before eating

FreshWorks™ containers work well with fruits or vegetables that require plenty of oxygen to stay fresh.

Examples include:

- Strawberries
- Raspberries
- Blueberries
- Broccoli
- Lettuce
- Carrots
- Brussel Sprouts
- Fresh Herbs
- Cauliflower
- Spinach

Results will vary depending on the type of produce and how it is handled.



Use and Care

To keep your Sistema® FreshWorks™ container looking its best, we recommend the following:

- Remove all labels/packaging and wash before use.
- Sistema® FreshWorks™ containers are made of materials that are safe for normal household dishwashers (top rack only). Be sure that the containers are secured on the top rack so that they do not come in contact with the dishwasher element to avoid melting. They can also be washed by hand in warm soapy water.
- Sistema® FreshWorks™ containers are not recommended for microwave or freezer use.
- Do not use utensils with sharp edges (i.e. knives) in the container, as they could scratch or scuff the container surface.
- Do not use abrasive cleaners or scrubbers since they may dull the finish.
- Snap the bottom of the base to the top of the lid for easy storage and organisation.

CAUTION: Sistema® FreshWorks™ containers are NOT recommended for microwave use. DO NOT use in a conventional oven, on a hot plate, under the grill, on the stove top or in convection microwave oven using convection settings.



FOOD SAFE



DISHWASHER SAFE
TOP RACK ONLY